X-Effects® LED Lens Cover

Installation Instructions





MATERIALS NEEDED:

- 1. Rosco X-Effects LED Lens Cover (Part No. 297000000020)
- 2. Rosco X-Effects LED Lens: 19°, 30°, 50°, or 70°

INSTALLATION STEPS:

- **1.** Remove Lens from the X-Effects LED Projector or from its original packaging.
- 2. Clean all dust or debris from both the Lens and Lens Cover.
- **3.** Ensure the O-ring is in place around the edge of the Lens Cover. (See Figure 1)
- **4.** Place Lens Cover on the top of the Lens and turn in clockwise motion until the cover is hand-tightened. Stop when there is resistance*. (*See Figure 2*)



*If over-tightened, the O-ring will begin to protrude, and the Lens will not be sealed. If this happens, unscrew the Lens Cover and repeat steps 3 & 4. (Figure 3 shows an over-tightened Lens Cover.)



